

DMX 채널 설정 방법

채널 번호	DIP SW									
	DIP번호	1	2	3	4	5	6	7	8	9
	십진수	1	2	4	8	16	32	64	128	256
CH1	1	1	0	0	0	0	0	0	0	0
CH2	4	0	0	1	0	0	0	0	0	0
CH3	7	1	1	1	0	0	0	0	0	0
CH4	10	0	1	0	1	0	0	0	0	0
CH5	13	1	0	1	1	0	0	0	0	0
CH6	16	0	0	0	0	1	0	0	0	0
CH7	19	1	1	0	0	1	0	0	0	0
CH8	22	0	1	1	0	1	0	0	0	0
CH9	25	1	0	0	1	1	0	0	0	0
CH10	28	0	0	1	1	1	0	0	0	0
CH11	31	1	1	1	1	1	0	0	0	0
CH12	34	0	1	0	0	0	1	0	0	0
CH13	37	1	0	1	0	0	1	0	0	0
CH14	40	0	0	0	1	0	1	0	0	0
CH15	43	1	1	0	1	0	1	0	0	0
CH16	46	0	1	1	1	0	1	0	0	0
CH17	49	1	0	0	0	1	1	0	0	0
CH18	52	0	0	1	0	1	1	0	0	0
CH19	55	1	1	1	0	1	1	0	0	0
CH20	58	0	1	0	1	1	1	0	0	0

채널 번호	DIP SW									
	DIP번호	1	2	3	4	5	6	7	8	9
	십진수	1	2	4	8	16	32	64	128	256
CH21	61	1	0	1	1	1	1	0	0	0
CH22	64	0	0	0	0	0	0	1	0	0
CH23	67	1	1	0	0	0	0	1	0	0
CH24	70	0	1	1	0	0	0	1	0	0
CH25	73	1	0	0	1	0	0	1	0	0
CH26	76	0	0	1	1	0	0	1	0	0
CH27	79	1	1	1	1	0	0	1	0	0
CH28	82	0	1	0	0	1	0	1	0	0
CH29	85	1	0	1	0	1	0	1	0	0
CH30	88	0	0	0	1	1	0	1	0	0
CH31	91	1	1	0	1	1	0	1	0	0
CH32	94	0	1	1	1	1	0	1	0	0
CH33	97	1	0	0	0	0	1	1	0	0
CH34	100	0	0	1	0	0	1	1	0	0
CH35	103	1	1	1	0	0	1	1	0	0
CH36	106	0	1	0	1	0	1	1	0	0
CH37	109	1	0	1	1	0	1	1	0	0
CH38	112	0	0	0	0	1	1	1	0	0
CH39	115	1	1	0	0	1	1	1	0	0
CH40	118	0	1	1	0	1	1	1	0	0

채널 번호	DIP SW									
	DIP번호	1	2	3	4	5	6	7	8	9
	십진수	1	2	4	8	16	32	64	128	256
CH41	121	1	0	0	1	1	1	1	0	0
CH42	124	0	0	1	1	1	1	1	0	0
CH43	127	1	1	1	1	1	1	1	0	0
CH44	130	0	1	0	0	0	0	0	1	0
CH45	133	1	0	1	0	0	0	0	1	0
CH46	136	0	0	0	1	0	0	0	1	0
CH47	139	1	1	0	1	0	0	0	1	0
CH48	142	0	1	1	1	0	0	0	1	0
CH49	145	1	0	0	0	1	0	0	1	0
CH50	148	0	0	1	0	1	0	0	1	0
CH51	151	1	1	1	0	1	0	0	1	0
CH52	154	0	1	0	1	1	0	0	1	0
CH53	157	1	0	1	1	1	0	0	1	0
CH54	160	0	0	0	0	0	1	0	1	0
CH55	163	1	1	0	0	0	1	0	1	0
CH56	166	0	1	1	0	0	1	0	1	0
CH57	169	1	0	0	1	0	1	0	1	0
CH58	172	0	0	1	1	0	1	0	1	0
CH59	175	1	1	1	1	0	1	0	1	0
CH60	178	0	1	0	0	1	1	0	1	0

채널 번호	DIP SW									
	DIP번호	1	2	3	4	5	6	7	8	9
	십진수	1	2	4	8	16	32	64	128	256
CH61	181	1	0	1	0	1	1	0	1	0
CH62	184	0	0	0	1	1	1	0	1	0
CH63	187	1	1	0	1	1	1	0	1	0
CH64	190	0	1	1	1	1	1	0	1	0
CH65	193	1	0	0	0	0	0	1	1	0
CH66	196	0	0	1	0	0	0	1	1	0
CH67	199	1	1	1	0	0	0	1	1	0
CH68	202	0	1	0	1	0	0	1	1	0
CH69	205	1	0	1	1	0	0	1	1	0
CH70	208	0	0	0	0	1	0	1	1	0
CH71	211	1	1	0	0	1	0	1	1	0
CH72	214	0	1	1	0	1	0	1	1	0
CH73	217	1	0	0	1	1	0	1	1	0
CH74	220	0	0	1	1	1	0	1	1	0
CH75	223	1	1	1	1	1	0	1	1	0
CH76	226	0	1	0	0	0	1	1	1	0
CH77	229	1	0	1	0	0	1	1	1	0
CH78	232	0	0	0	1	0	1	1	1	0
CH79	235	1	1	0	1	0	1	1	1	0
CH80	238	0	1	1	1	0	1	1	1	0

채널 번호	DIP SW									
	DIP번호	1	2	3	4	5	6	7	8	9
	십진수	1	2	4	8	16	32	64	128	256
CH81	241	1	0	0	0	1	1	1	1	0
CH82	244	0	0	1	0	1	1	1	1	0
CH83	247	1	1	1	0	1	1	1	1	0
CH84	250	0	1	0	1	1	1	1	1	0
CH85	253	1	0	1	1	1	1	1	1	0
CH86	256	0	0	0	0	0	0	0	0	1
CH87	259	1	1	0	0	0	0	0	0	1
CH88	262	0	1	1	0	0	0	0	0	1
CH89	265	1	0	0	1	0	0	0	0	1
CH90	268	0	0	1	1	0	0	0	0	1
CH91	271	1	1	1	1	0	0	0	0	1
CH92	274	0	1	0	0	1	0	0	0	1
CH93	277	1	0	1	0	1	0	0	0	1
CH94	280	0	0	0	1	1	0	0	0	1
CH95	283	1	1	0	1	1	0	0	0	1
CH96	286	0	1	1	1	1	0	0	0	1
CH97	289	1	0	0	0	0	1	0	0	1
CH98	292	0	0	1	0	0	1	0	0	1
CH99	295	1	1	1	0	0	1	0	0	1
CH100	298	0	1	0	1	0	1	0	0	1

채널 번호	DIP SW									
	DIP번호	1	2	3	4	5	6	7	8	9
	십진수	1	2	4	8	16	32	64	128	256
CH101	301	1	0	1	1	0	1	0	0	1
CH102	304	0	0	0	0	1	1	0	0	1
CH103	307	1	1	0	0	1	1	0	0	1
CH104	310	0	1	1	0	1	1	0	0	1
CH105	313	1	0	0	1	1	1	0	0	1
CH106	316	0	0	1	1	1	1	0	0	1
CH107	319	1	1	1	1	1	1	0	0	1
CH108	322	0	1	0	0	0	0	1	0	1
CH109	325	1	0	1	0	0	0	1	0	1
CH110	328	0	0	0	1	0	0	1	0	1
CH111	331	1	1	0	1	0	0	1	0	1
CH112	334	0	1	1	1	0	0	1	0	1
CH113	337	1	0	0	0	1	0	1	0	1
CH114	340	0	0	1	0	1	0	1	0	1
CH115	343	1	1	1	0	1	0	1	0	1
CH116	346	0	1	0	1	1	0	1	0	1
CH117	349	1	0	1	1	1	0	1	0	1
CH118	352	0	0	0	0	0	1	1	0	1
CH119	355	1	1	0	0	0	1	1	0	1
CH120	358	0	1	1	0	0	1	1	0	1

